

ARCO SAFE TOOL BOX TALKS

Aerial Boom Lifts

ONLY QUALIFIED/AUTHORIZED AND COMPETENTLY TRAINED PERSONNEL ARE ALLOWED TO OPERATE AERIAL LIFTS!

OPERATORS MUST BE
TRAINED ON THE SPECIFIC
TYPE/MODEL THEY WILL BE
OPERATING ON THE
PROJECT SITE!

OPERATORS MUST HAVE READ AND UNDERSTAND THE OPERATORS MANUAL!

ANYONE IN AN AERIAL BOOM LIFT MUST BE TIED OFF!

NEVER STAND OR CLIMB ON THE RAILS OF A LIFT – NEVER!

PRIOR TO OPERATING A LIFT YOU SHOULD:

- Inspect the job site to look for obstacles you will have to maneuver around, such as:
 - o Soft, unstable, or uneven ground
 - Other equipment or workers
 - Overhead power lines
 - o Pedestrians and vehicles
- Inspect your fall arrest equipment before use fall arrest equipment must be a
 full body harness with an appropriate sized lanyard or retractable.
 Lanyards/retractables must be sized to prevent contact with a lower level.
- You must attach to the anchor point as soon as you enter the work basket.

WHILE OPERATING A LIFT YOU SHOULD:

ALWAYS

- Keep your body inside the basket
- Avoid hazards including pinch points and trapping your body between the lift and solid objects
- o 100% TIE OFF
- o Move the basket to where you need don't overreach the rails.
- o Keep the lift clear of electrical lines
- Make sure you're on level/stable ground
- o Follow the manufacturer's restrictions and recommendations

NEVER

- Stand on the rails
- Overload the lift
- Get closer than 10' to power lines
- o Put a lateral load on the lift
- Stand on a bucket, ladder, or anything other than the floor of the basket
- Exit the basket by climbing over the rails

